



COOL BOXX

The Official Iceless Driver Cooling System of



Cool Boxx Quick Start Guide

- Cool Boxx comes pre-tested but with minimal water, add distilled water to top of fill tube.
- Upon first use of system connected to Cool Boxx Vest/Shirt make sure to top off with distilled water.
- Do not over tighten fill tube cap.
- Thermostat set to 36°F from the factory. If this is too cold, follow procedure below to increase temp:
 - press up arrow to increase temp and
 - down arrow to decrease temp
- Connect plus and minus wires to respective battery terminal or kill switch or fuse. If extending wire, use at least 10g. If using a fuse needs to be at least 40 amps.
- It is recommended to pre-cool Cool Boxx for 5 minutes prior to session.
- Mount in an area where there is sufficient airflow such as the passenger compartment.
- If mounted in an area with limited air flow such as the trunk or in a car with factory lexan door windows, outside air will need to be guided into the Boxx intake. This can be done with a 4" nacaduct and duct hosing.
- Check water levels regularly, recommended at least prior to each event.
- If you have any further questions, please email us at info@coolboxx.la



Visit Our Website
www.coolboxx.la

